

PART INFORMATION

No : 004 / PI / PART / IAMI / il / 2012
Tanggal : 17 Feb 2012
Perihal : MODEL TYPE TRANSMISSION FVZ34

2-20 TRANSMISSION ASM



MANUAL TRANSMISSION ASM AND CASE							2-20
							FIG-NO.
KEY NO.	PART NUMBER	RECOMMEND DATE	CLASS	PART NAME	APPLIED MODEL / RESTRICTION / REMARKS		
1	-D-			TRANSMISSION ASM; MANUAL			
	8-98183-350-1	1104-	01 A	EXC. PTO ZF TRANS RR(BDW)			
	8-98183-351-1	1104-	01 A	PTO ZF TRANS RR(BDW)			
2	---			HOUSING; CLU			
	1-31111-183-0	1104-	01 A				
24	---			COVER; CHECK HOLE, DUST			
	1-31119-059-0	1104-	01 A				
25	---			GASKET; COVER			

ZF9S1110 DD

PART CATALOG FVZ
PART NO. 1-88711 393-A

MANUAL TRANSMISSION ASM AND CASE							2-20
							FIG-NO.
KEY NO.	PART NUMBER	RECOMMEND DATE	CLASS	PART NAME	APPLIED MODEL / RESTRICTION / REMARKS		
1	-D-			TRANSMISSION ASM; MANUAL			
	8-98183-350-1	1104-	01 A	EXC. PTO ZF TRANS RR(BDW)			
	8-98183-351-1	1104-	01 A	PTO ZF TRANS RR(BDW)			
2	---			HOUSING; CLU			
	1-31111-183-0	1104-	01 A				
24	---			COVER; CHECK HOLE, DUST			
	1-31119-059-0	1104-	01 A				
25	---			GASKET; COVER			

ZF9S1115 TD

PART CATALOG FVZ (Changed)
PART NO. 1-88711 393-B